August International Ltd
United Kingdom
Telephone:+44 (0) 845 250 0586
www.augustint.com

August®

# User Manual

DA900C

## 9 Inch Digital & Analogue LCD TV

# User Manual

Thank you for buying our August TV. You may already be familiar with using a similar product but please take time to read these instructions carefully. It is designed to familiarise you with the product's many features and to ensure that you get the very best from your purchase.

**Safety**

To ensure your safety and the safety of others, please ensure you read the Safety Instructions before you use this product.

**Disposal**

Please ensure the product and its accessories are disposed in compliance with WEEE (Waste Electrical and Electronic Equipment) Directive and other regulations. Please check with your local authority for disposal regulations.

**Customer Service:**

If you need help, please contact our Customer Service:
Telephone: +44 (0) 845 250 0586
Email: service@augustint.com

# Quick Start Guide

## DA900C

1. It is suggested that you use a roof top aerial when scanning for TV channels for the first time, if any signal is detected, the channel information will be saved on the TV, you may then switch back to the portable antenna supplied and change your location to find the best place to receive the signal.

2. Connect the device to the mains power, press POWER on the remote to turn on the device, or press and hold POWER on the device for 1.5 seconds to turn it on.

3. The MODE on the device or remote allows you to switch between: DTV (Digital Freeview TV & Media Player), ATV (Analogue TV), AV IN, BRIGHTNESS, CONTRAST, COLOR, SCALE (Aspect Ratio) and INVERT.

4. When turning on the device for the first time, "Initial Install" will show, follow the instructions to select OSD Language and Area, then press ENTER, it will ask whether to install, select YES, the auto search will then start. Once the search has finished, press CH+, CH- or EPG to select channels. Press TV/R to switch between Freeview TV and Radio channels.

5. If you have done the first time installation before, and would like to search for Digital Freeview channels again, or if you have moved to a different region and need to scan channels again, press MODE to switch to Digital TV & Media Player mode, press MENU, select "Digital TV" by pressing ENTER, select "Installation", then select "Auto Search", press ENTER to start the search. Once the search has finished, press CH+, CH- or EPG to select channels. Press TV/R to switch between Freeview TV and Radio channels.

6. To search for Analogue TV, press MODE repeatedly until it shows ATV, press LEFT or RIGHT to switch to the Analogue TV mode. Press MENU, it shows the ATV SETUP menu, set the TV FORMAT to "PAL I" for UK, then move to AUTO SEARCH, press ENTER to start the search.

7. To play video, music, or photos on a SD card or memory stick, press MODE to switch to Digital TV & Media Player mode, insert the SD card or memory stick to the card slot or USB port, press MENU to select “Movie”, “Music”, or “Photo”, press ENTER or PLAY to start playing, press MENU to stop and exit to the main menu. During the photo playback, press UP for the mirror effect, press again to back to normal, press DOWN for upside down effect, press again to back to normal, press RIGHT to rotate clockwise, press LEFT to rotate anticlockwise, press ENTER for photo slideshow, photos in the selected folder will show repeatedly.

8. Please note the included portable antenna may only be used in areas where signal is very strong. As mentioned on the Freeview website, only some households might be able to use a set top aerial at present. This only applies if you live in an area with coverage close to a transmitter, but reception would still be unreliable and they strongly recommend that you use a roof top aerial for good reception.

   The reception will improve along with the progress of the Digital Switchover Program. Reception may also be affected by various factors such as how close you are to transmitters, tall buildings, thick walls, ceilings and weather etc.

9. For any further queries, please telephone August International Ltd helpline +44 (0) 845 250 0586 or email service@augustint.com

# Contents


**1. Safety Instructions** 1

**2. Accessories** 3

**3. Part Names and Functions** 4

**4. Connection** 9

**5. Basic Operation** 12

**6. Digital Freeview TV (DVB-T)** 13

**7. Digital TV Recording** 19

**8. Card Reader & USB Functions** 20

**9. Games** 22

**10. Analogue TV (ATV)** 23

**11. Specifications** 25

**12. Troubleshooting** 27

**13. Warranty** 28

# 1. Safety Instructions

## Storage and Use



Keep this machine away from hot or cold places. The storage temperature of this machine is -20~ 60℃, the application temperature of this machine is 5~ 35℃.



Keep the TV set away from water or damp environment.

Never expose the TV set to moisture,dust oil or smoke.



Avoid dropping or exposing to impacts.



Never put this machine in containers that are unstable as this may cause damage.

Never extrude or chafe this machine with sharp objects.

## Maintenance

Please unplug all connection wires before start cleaning this machine.



Please wipe the display screen and buttons with a soft cloth. Only clean the screen with professional LCD TV screen cleanser.




Never wipe this machine with an abrasive cloth, detergent powder, alcohol and benzene etc. various propellants or chemical cleaning products.



## Operation Precautions

1.Use only the supplied power adaptor with this device. Failure to do so can cause damage to the device and risk personal injury.

2.For the sake of safety, when you do not intend to use the display, please switch off the AC adaptor or car adaptor.

## Earphone Operation Precautions

1.Please do not tune your headphone / earphone at high volumes, otherwise, it may lead to ear damage.

2.For open-designed earphone, to avoid annoying those close by, please tune down the volume.

3.In case of any tinnitus, please turn down the volume or stop using this machine.

4.It is recommended by aurists that the earphones should not be used continuously for a prolonged period.

### ⚠ Warning

For the sake of safety for yourself and others, please do not watch the TV while driving.

### ⚠ Special Notice

A few highlights or dark spots may appear on the LCD screen. It is a very common phenomenon of active matrix display technology, and does not mean any defects or faults. Never try to repair this machine by yourself. In case of any fault or failure, please turn off the display at once, and notify our Company or the corresponding dealer. The display is made up of many precision electronic components. Any disassembly or modification may lead to further damage.

## 2. Accessories

| | |
|---|---|
| AC/DC adaptor | Remote control |
| Stand | Digital TV antenna |
| Telescopic antenna | AV cable |
| Earphones | User manual |



## 3. Part Names and Functions

### 3.1 Front




1. IR receiver window
2. LCD display

### 3.2 Back




1. Speakers
2. Stand

### 3.3 Left




1. Antenna input jack
2. USB jack
3. AV OUT
4. AV IN
5. Earphone jack
6. 12V DC IN jack

### 3.4 Right




1. SD/MMC card slot
2. ⏯ Play / Pause / Resume
3. MENU Main Menu / Exit the menu
4. ➡/⏩ Right / Forward
5. ⬅/⏪ Left / Reverse
6. ↵ Enter/ Confirm
7. CH-/⬇/⏮ Channel Down/ Down/ Previous Track or Chapter
8. CH+/⬆/⏭ Channel Up/ Up / Next Track or Chapter
9. Volume Up / Volume Down
10. ⏻ / MODE

Press and hold to power on/off the device.

Press repeatedly for mode switch. More details can be found on page 12.



### 3.5 Remote Control

#### 3.5.1 Remote Button Functions

1. ⏻ Power on/off the device
2. MODE Mode switch
3. TV/R Freeview TV and Radio switch
4. AUDIO Select audio channel or audio language
5. 0-9 Numbers
6. REC Start recording or stop recording
7. MENU Main Menu / Exit the menu
8. ⏭ Next track or chapter
9. ⏶/CH+ Up / Channel Up
10. ⏮ Previous track or chapter
11. ⏴ Left / confirm or change settings in ATV mode
12. ⏵ Right / confirm or change settings in ATV mode
13. ENTER Confirm settings
14. ⏪ Reverse in media player mode
15. ⏩ Forward in media player mode
16. CH-/⏷ Down / Channel Down
17. VOL+ Volume Up
18. VOL- Volume Down
19. ⏯ Play / Pause / Resume
20. MUTE Switch off / on the sound
21. MOVE Move channels when using Channel Organizer
22. FAV Set favourite channels when using Channel Organizer
    Shortcut for favourite channels list when watching TV or listening to the radio
23. ZOOM Zoom in on the picture
24. LOCK Set parental lock when using Channel Organizer
25. S.TITLE Switch on / off subtitle
26. EPG 7 day electronic program guide
    Press RIGHT and UP/DOWN to view today's program information.
    Press ⏩ to view next days program information, press ⏪ to come back.
27. INFO Freeview channel information
28. TTX Freeview interactive teletext



### 3.5.2 Use of the Remote Control

Please remove the PVC packaging before using the remote control for the first time.

1.Do not expose the remote control to direct sunlight or very strong/bright light.

2.Do not drop or step on the remote control or subject it to shocks.

3.Keep the remote control away from extreme hot or humid environment.

4.Keep the remote control away from water.

### ■ Operating range

1.The IR sensor on the remote control should aim directly to the sensor on the front of the device. It may not be possible to operate the device if there are obstacles between it and the remote sensor.

2.Use the remote control no further than 5 meters away from the sensor.

3.The receiving angle range should be ±30°.




### ■ Replacing the battery

If the remote control does not function or if the operating range becomes reduced, replace the old battery with a new one.




Remove the old battery, then insert the new battery into the battery holder with the + side facing upwards.

Lithium battery(CR2025)





Push back the holder.

***Note:**

1.Please ensure proper disposal of used batteries.

2.To prevent leakage of fluid from the lithium battery, remove the battery when not using the remote control for a long period of time. If the battery leaks fluid, carefully wipe it out of the battery case, then change to a new lithium battery.

# 4.Connection

### 4.1 Connecting the power supply

1.Connect the DC output of the AC/DC adaptor to the DC IN 12V jack on the device.

2.Plug the power adaptor to the AC power socket.




### 4.2 Connecting the earphones

Connect the earphone plug to the earphone jack on the device.




***Note:**

If earphones are used, sound is only transmitted through the earphones, and no sound is available from the stereo speakers of the device.



### 4.3 Connecting to a TV set via AV Output

Turn off all devices before connecting or disconnecting any cables.




***Note:**

The AV output function is only available in Freeview (DVB-T) and Media player mode.

### 4.4 Connecting to an Audio/Video device via AV Input

Turn off all devices before connecting or disconnecting any cables.




***Note:**

To use the AV IN function of this device, please set it to AV IN mode first.



## 5. Basic Operation

### 5.1 Turning on/off the device

#### 5.1.1 Turn power on

Connect the device to the mains power, press POWER on the remote to turn on the device, or press and hold POWER on the device for 1.5 seconds to turn it on.

#### 5.1.2 Turn power off

Press POWER on the remote to turn off the device, or press and hold POWER on the device for 1.5 seconds to turn it off.

### 5.2 Mode settings

Press MODE repeatedly to select between the following modes:
DTV: Freeview TV & Media Player, press RIGHT to change
ATV: Analogue TV, press RIGHT to change
AV IN: AV input, press RIGHT to change
BRIGHTNESS: Press LEFT or RIGHT to change
CONTRAST: Press LEFT or RIGHT to change
COLOR: Press LEFT or RIGHT to change
HUE: Press LEFT or RIGHT to change
SCALE: Press LEFT or RIGHT to change aspect ratio to 16:9 or 4:3
INVERT: Press LEFT or RIGHT to change the display to upside down or normal

# 6. Digital Freeview TV (DVB-T)

If the device is not in the Digital Freeview TV mode, press MODE repeatedly until it shows DTV, press LEFT or RIGHT to change .

## 6.1 Channel Manager

Channel Manager allows the user to sort, edit, delete, and classify the channels.

In Digital TV mode, select Channel Manager, press ENTER for the submenus.

### 6.1.1 Channel Organizer

Channel organizer is used to set favourite channels, change channel positions, lock and delete channels, and edit channel's name.

1. Channel Organizer can be accessed by selecting MENU -> Digital TV -> Channel Manager -> Channel Organizer.

2. If there is no channel saved on the TV, Channel Organizer can not be accessed, and it will show “Channel not available”.

3. Use UP/DOWN to select the channel you want to edit.
   - Press RED to delete or undelete a channel, it will ask you to enter the password, the system default password is 0000.
   - Press GREEN to select or cancel a favourite.
   - Press YELLOW to set or cancel a channel's position change.
   - Press BLUE to lock or unlock a channel, it will ask you to enter the password, the system default password is 0000.

4. To change the channel name, use UP/DOWN to select the channel line, press LEFT/RIGHT to enter the page to change the name, press RED/GREEN /YELLOW/BLUE to edit the name.

5. Press MENU to exit Channel Organizer.

### 6.1.2 Channel Sorting

It allows the user to sort the channels by area, alphabetically or by number sequence.

1. Channel Sorting can be accessed by selecting MENU-> Digital TV-> Channel Manager->Channel Sorting.

2. If there is no channel saved on the TV, Channel Sorting can not be accessed, and it will show “Channel not available”.

3. Press UP/DOWN to select:

① First Option: Sorting by area, press RIGHT to enter the area list, use UP/DOWN to select, press ENTER to confirm.

② Second Option: Sorting alphabetically or by number sequence, press RIGHT to enter the option list, use UP/DOWN to select, press ENTER to confirm.

4. Sorting rules can be selected by pressing RIGHT/UP/DOWN/LEFT.

5. After sorting rules is selected, press ENTER to confirm, it will ask “Are you sure?”, select “Yes” to confirm and to proceed the sorting, or select “No” to cancel.



6. Press MENU to exit Channel Sorting.

### 6.1.3 Channel Grouping

It allows the user to sort channels into 8 different categories: News, Science, Sports, Movie, Kids, Music, Fashion and None.

1. Channel Sorting can be accessed by selecting MENU-> Digital TV-> Channel Manager->Channel Grouping.

2. If there is no channel saved on the TV, Channel Grouping can not be accessed, and it will show “Channel not available”.

3. Use UP/DOWN to select the channel, and then select the category by pressing the numbers (1-8).

4. After setting, press MENU it will show “Successfully updated”.

### 6.1.4 Edit Channels

It allows the user to add and edit channels.

1. Edit Channels can be accessed by selecting MENU-> Digital TV-> Channel Manager-> Edit Channels.

2. If there is no channel saved on the TV, Edit Channels can not be accessed, and it will show “Channel not available”.

3. To add a new channel, press RED, and then press UP/DOWN to select between the 6 parameters as shown:

①Area Name: press RIGHT to enter the area list, use UP/DOWN to select, press ENTER to confirm.

②Carrier: press RIGHT to enter the carrier list, use UP/DOWN to select, press ENTER to confirm.

③Channel Name: press RIGHT to enter the edit page, use RED/GREEN /YELLOW/BLUE to edit, press ENTER to confirm.

④Audio PID: can be changed by pressing the numbers.

⑤Video PID: can be changed by pressing the numbers.

⑥PCR PID: can be changed by pressing the numbers.

⑦Once finish the settings, press ENTER to confirm, it will show “Successfully updated” and return to Edit Channels.

⑧During setup, press MENU at any time to cancel and exit to Edit Channels.

4. To edit a channel, press YELLOW, and then press UP/DOWN to select between the 4 parameters as shown:

①Channel Name: press RIGHT to enter the edit page, use RED/GREEN/ YELLOW/BLUE to edit, press ENTER to confirm.

②Audio PID: can be changed by pressing the numbers.

③Video PID: can be changed by pressing the numbers.

④PCR PID: can be changed by pressing the numbers.

⑤Once finish the settings, press ENTER to confirm, it will show “Successfully updated” and return to Edit Channels.

⑥During setup, press MENU at any time to cancel and exit to Edit Channels.

**6.1.5 Delete All**

To delete all the TV and Radio channels, select MENU-> Digital TV-> Channel Manager-> Delete All.

1. Use UP/DOWN to select TV channels, it will ask “ Delete all TV channels?”, select “Yes” to confirm and proceed the delete, select “No” to cancel.
2. Use UP/DOWN to select Radio channels, it will ask “ Delete all Radio channels?”, select “Yes” to confirm and proceed the delete, select “No” to cancel.



## 6.2 Installation

Installation is for searching TV and Radio channels, it can be accessed by selecting MENU-> Digital TV-> Installation.

Pressing ENTER, it gives two search options: Auto Search and Manual Search.

**6.2.1 Auto Search**

Select Auto Search, press ENTER, it will start the search.

After searching, the system will automatically exit the searching page, save program information and return to Installation menu, press MENU to exit.



**6.2.2 Manual Search**

If you know a channel's broadcasting frequency and bandwidth, using manual search to find the channel can be quicker.

Select Manual Search, press ENTER, it will ask you to provide two parameters:

①Freq (KHz): scanning frequency, the default is 474000 KHz, use numbers or LEFT/RIGHT to change.

②Band Width: use LEFT/RIGHT to select.

After setting, press ENTER to start the search. After searching, the system will automatically exit the searching page, save program information and return to Installation menu, press MENU to exit.

## 6.3 Configuration

Configuration menu has the following options: On Screen Display, TV, System Setup, Time, Wakeup Timer and Parental Lock. It can be accessed by selecting MENU->Digital TV->Configuration.

**6.3.1 OSD (On Screen Display)**

Through OSD, you can set the interface pattern.



Left of the menu lists all the options under OSD. Press UP/DOWN to select an option.

1. OSD: supports 5 menu patterns, press LEFT/RIGHT to select between Theme1-5.
2. OSD Timeout: sets the display time of an information dialog window, press LEFT/RIGHT to select between 1-6 seconds, the system default is 3seconds.
3. OSD Trans: sets the transparency of the menu, press LEFT/RIGHT to adjust from 0%-60%.
4. OSD Language: the system supports multi-language user interface, press RIGHT to enter the language list, use UP/DOWN to select, press ENTER to confirm.



5. 1st Audio Language: press RIGHT to enter Audio Language list, use UP/DOWN to select, press ENTER to confirm.
6. 2nd Audio Language: press RIGHT to enter Audio Language list, use UP/DOWN to select, press ENTER to confirm.
7. After setting, press ENTER to confirm, press MENU to exit the setup, it will show “Successfully updated”.

**6.3.2 TV**

This option allows the users to set their preferred TV output settings.



Left of the menu lists all the options. Press UP/DOWN to select an option.

1. Display Mode: press LEFT/RIGHT to select between AUTO, PAL, & SECAM, press ENTER to confirm and exit the setting. Or press UP/DOWN to select another option.

2. Aspect Ratio: press LEFT/RIGHT to select between 16:9, 4:3 Pan Scan, 4:3 Letter Box, press ENTER to confirm and exit the setting. Or press UP/DOWN to select another option.
3. Brightness: press RIGHT to enter the list, use UP/DOWN to select, press ENTER to confirm, press ENTER again to exit the setting, or press UP/DOWN to select another option.

4. Contrast: press RIGHT to enter the list, use UP/DOWN to select, press ENTER to confirm, press ENTER again to exit the setting, or press UP/DOWN to select another option.



5. HUE: press RIGHT to enter the list, use UP/DOWN to select, press ENTER to confirm, press ENTER again to exit the setting, or press UP/DOWN to select another option.



6. Saturation: press RIGHT to enter the list, use UP/DOWN to select, press ENTER to confirm, press ENTER again to exit the setting, or press UP /DOWN to select another option.



7. After setting, press ENTER to confirm, press MENU to exit the setup, it will show “Successfully updated”.

### 6.3.3 System Setup



You can set EQ Setup, Surround, LCN (Logical Channel Number) and Area in System Setup.

Press UP/DOWN to select an option, use LEFT/RIGHT to change the settings. After setting, press ENTER to confirm, press MENU to exit the setup, it will show “Successfully updated”.

### 6.3.4 Time

You can set Timer Mode, Date, Time, GMT Offset, and Summer Time under Time menu. There are two Timer modes, one is Auto, and one is Manual.

The system default is Auto timer mode, press UP/DOWN to select Timer Mode or GMT Offset, use RIGHT/LIFT to change.





In Manual timer mode, press UP/DOWN to select an option, use RIGHT/LEFT or numbers to change the Date, Time, GMT Offset or Summer Time.



After setting, press ENTER to confirm, press MENU to exit the setup, it will show “Successfully updated”.

### 6.3.5 Wakeup Timer

This option allows you to switch off / on the device automatically, set a scheduled time recording, or set a reminder for the program you do not want to miss.



You can set Timer Mode, Wakeup Mode, Wakeup Message, Wakeup Channel, Wakeup Date, Time, Duration and Partition.

1. Timer No.: the number of this Wakeup Timer setting, use LEFT/RIGHT to change.
2. Timer Mode: use LEFT/RIGHT to select between Once, Daily, Weekly, Yearly or Off.

3. Wakeup Mode: use LEFT/RIGHT to choose to show a message, switch to a channel you want to watch, switch off/on the device or set a scheduled TV recording.

Note:
1) In order for the device to turn on automatically, it must have been turned off using the Wakeup Timer.
2) If the device was switched off using the Wakeup Timer, to turn it on manually, press the POWER button twice.

① Wakeup Message: use LEFT/RIGHT to select between Birthday, Anniversary or General.
② Wakeup Channel: use LEFT/RIGHT to select a channel from the channel list.

4. Wakeup Date: press RIGHT to enter the Calendar, use UP/DOWN/LEFT/RIGHT to select a date.

5. On Time: use numbers to set the starting time.

6. Duration: use numbers to set how long you want to watch or record the program.

7. Default Partition: this is for scheduled recording only, press RIGHT, it will show “Device List”, if the TV connects to an USB stick, it only shows one device on the list, if the TV connects to an external hard drive which has number of partitions, it will show the partition list, select the appropriate, press ENTER, it will ask to confirm whether to change, if you want to change, select “Yes” then press ENTER, otherwise select “No”. It will show “Set successfully”.

After setting, press ENTER to confirm, press MENU to exit the setup, it will show “Successfully updated”.

### 6.3.6 Parental Lock

User can change system password under this option.

Enter the old password, if it is correct, the cursor will move to Enter New Password option, enter and confirm the new password. The system will show “Password changed”.

The system default password is 0000.

### 6.4. Software Upgrade

This function is for manufacturer use only.

### 6.5 Factory Default

To restore the system configuration to factory default, press MENU, select Digital TV-> Factory Default, press ENTER.

It will ask whether you want to perform the factory default, select [No] to cancel or select [Yes] to confirm.

### 6.6 Version

This provides the hardware, software and system information.

## 7. Digital TV Recording

The device supports recording Freeview TV to an USB memory stick or external hard drive (FAT32, USB2.0) via the USB port.

Before starting the recording, connect an USB stick or external hard drive, which has sufficient space left, to the device first.

### 7.1 Real Time TV Recording

Press REC on the remote to start the recording, it will show “REC” on the screen, press REC again to stop the recording, it will ask “Do you want to stop recording”, choose “Yes” to stop or “No” to carry on recording.

Press YELLOW during the recording, it allows you to set the duration of the recording, press RIGHT to choose: 15 min, 30 min, 45 min, 60 min, 75 min, 90 min, 105 min, 120 min or disable, press ENTER to confirm and exit.

Press INFO during the recording, it will show how long the record has been on, the name of the channel, and how many space has left on your USB stick or external hard drive, press INFO again to exit.

The recorded program is saved in a new folder “PVR” in your USB stick or external hard drive and is in MPG video format. It can be viewed by pressing MENU then selecting Movie.

Press MENU, then select Disk Manger, it shows all the recorded programs stored in the USB stick or external hard drive, press GREEN repeatedly to select Play/Delete One / Delete All/ Rename a recorded program, press ENTER to confirm, press MENU to exit at any time.



### 7.2 Scheduled TV Recording

To set up a recording schedule, please make sure the device is on digital Freeview TV mode first. Then press MENU, select Digital TV by pressing ENTER, select Configuration, and then select Wakeup Timer. It shows the following options:

1. Timer No.: the number of this Wakeup Timer setting, use LEFT/RIGHT to change.
2. Timer Mode: use LEFT/RIGHT to select between Once, Daily, Weekly, Yearly or Off.
3. Wakeup Mode: select “Recorder” for scheduled recording, for the use of other available functions in this setting, please refer to page 18 in the user manual.
4. Wakeup Channel: use LEFT/RIGHT to select the channel you want to record.
5. Wakeup Date: press RIGHT to enter the Calendar, use UP/DOWN/LEFT/ RIGHT to select a date you want to record the program.
6. On Time: use numbers to set the starting time of the recording.
7. Duration: use numbers to set the duration of the recording.
8. Default Partition: press RIGHT, it will show “Device List”, if the TV connects to an USB stick, it only shows one device on the list, if the TV connects to an external hard drive which has number of partitions, it will show the partition list, select the appropriate, press ENTER, it will ask to confirm whether to change, if you want to change, select “Yes” then press ENTER, otherwise select “No”. It will show “Set successfully”.
9. Press MENU to exit the setting, it will show “Successfully updated”.

Please note the scheduled recording can only be activated when the device is ON and is in the Freeview TV mode.

.

When the recording starts, it will show “REC” on the screen, when it has finished, the “REC” will disappear. Press INFO during the recording, it will show the progress of the recording, the name of the channel, and how many space has left on your USB stick or external hard drive, press INFO again to exit.

The recorded program is saved in a new folder “PVR” in the USB stick or external hard drive and is in MPG video format. It can be viewed by pressing MENU then selecting Movie.

Press MENU, then select Disk Manger, it shows all the recorded programs stored in the USB stick or external hard drive, press GREEN repeatedly to select Play/Delete One/ Delete All/ Rename a recorded program, press ENTER to confirm, press MENU to exit at any time.

## 8. Card Reader & USB Functions

This player has built-in SD/MMC card reader and USB port. It supports the playback of MP3, JPEG and MPEG4 (AVI) files.

Insert a SD/MMC card or an USB memory stick to the card slot or USB port on the player.

### 8.1 Movie

Press MENU, select Movie, press ENTER, the Movie menu will show:



Use UP/DOWN to select a subtrack.



Press ENTER to view the video files in the subtrack.



Use UP/DOWN to select a movie you want to watch, press ENTER to confirm.



Press ▶▶ to search forward at 2, 4, 8 and 20 times of the normal speed.
Press ◀◀ to reverse at 2, 4, 8 and 20 times of the normal speed.
Press ⏮ to play the previous movie, press ⏭ for the next one.
Press ZOOM, a magnifying glass will show on the screen, press ▶▶ to zoom out and view the picture at 1/2, 1/3, or 1/4 times of the normal view. Press ◀◀ to zoom in and view the picture at 2, 3, or 4 times of the normal view, press LEFT or RIGHT to move the picture.
Press MENU to stop at any time, press again to exit the playback.

## 8.2 Music

Press MENU, select Music, press ENTER, the Music menu will show:



Use UP/DOWN to select a subtrack.



Press ENTER to view the music files in the subtrack.



Use UP/DOWN to select a file you want to play, press ENTER to confirm.

Press ▶▶ to search forward at 2, 4, 8 or 20 times of the normal speed.
Press ◀◀ to reverse at 2, 4, 8 or 20 times of the normal speed.
Press ⏮ to play the previous music file, press ⏭ for the next one.
Press MENU to stop at any time, press again to exit the playback.



### 8.3 Photo

Press MENU, select Photo, press ENTER, the Photo menu will show:



Use UP/DOWN to select a subtrack.



Press ENTER to view the photo files in the subtrack.

Use UP/DOWN to select a file you want to play, press ENTER to confirm.

Press ⏮ to play the previous photo, press ⏭ for the next one.
Press ZOOM, a magnifying glass will show on the screen, press ▶▶ to zoom out and view the picture at 1/2, 1/3, or 1/4 times of the normal view. Press ◀◀ to zoom in and view the picture at 2, 3, or 4 times of the normal view, press LEFT or RIGHT to move the picture.
Press ENTER for photo slideshow, photos in the selected folder will show repeatedly.
Press MENU to stop at any time, press again to exit the playback.

# 9. Games

Games can be accessed by selecting Menu ->Game-> Native Games.



Press UP/DOWN to select the game you want to play, press ENTER to confirm. The games are played using UP/DOWN /LEFT/RIGHT buttons. To exit the game, press ENTER to pause, and then select Exit Game.



# 10. Analogue TV (ATV)

To search for Analogue TV, press MODE repeatedly until it shows ATV, press LEFT or RIGHT to switch to the Analogue TV mode.

Press MENU, the ATV SETUP menu will show as follows:

Use UP/DOWN to select the TV FORMAT, AUTO SEARCH, SKIP SWITCH, FINE TUNE, press ENTER to confirm, press MENU to exit at any time during the setting.

### 10.1 TV FORMAT

Use UP/DOWN to select the correct TV format for where you are, press ENTER to confirm.




***Note:**

Set the TV FORMAT to “PAL I” for UK.

### 10.2 AUTO SEARCH

The device will search for programs automatically if selecting AUTO SEARCH.

It will show as follows:

or

or






### 10.3 SKIP SWITCH

The SKIP SWITCH allows you to hide any channels, and they will be skipped when selecting channels using CH+ or CH-.

Move to the channel you want to skip, press MENU, then select SKIP SETUP, the following menu will show:

Use UP/DOWN to select SKIP ON, press ENTER to confirm, then press MENU to exit.

To turn the SKIP OFF for a channel, press the channel's number, press MENU, use UP/DOWN to select SKIP OFF, press ENTER to confirm, then press MENU to exit.

### 10.4 FINE TUNE

The device will tune the program finely if selecting FINE TUNE.

Use LEFT/RIGHT to tune, and the following will show:

***Note:**

If the signal is too weak, the image will remain poor whatever you do, and may output loud noise, shaking images and inferior sound etc., which is not the TV's fault. If the image remains poor when using the telescopic antenna, please try to use a roof top aerial or an amplified external antenna.

# 11. Specifications

| | |
|---|---|
| LCD Display | Screen size: 9 Inch<br>Resolution: 640X234 pixels<br>Aspect Ratio: 16:9<br>Brightness: 250 cd/m$^2$<br>Contrast: 150:1 |
| DVB-T Decode Standard | MHEG5 |
| DVB-T Band Width | 6, 7 ,8 |
| DVB-T Frequency | VHF: 177.5~226.5 MHz<br>UHF: 474~858 MHz |
| Analogue TV Format | PAL-I , DK, BG<br>SECAM-L, DK |
| Analogue TV Frequency | VHF: 48.25 ~ 160.25 MHz<br>168.25 ~ 456.25 MHz<br>UHF: 464.25~863.25 MHz |
| AV In | System: PAL, NTSC, SECAM<br>CVBS Input: 1.0Vp-p/75ohm<br>Audio Input: 1Vrms~2Vrms |
| AV Out | CVBS Output: 1.0Vp-p/75ohm<br>System: PAL, NTSC |
| Antenna Input | Impedance: 75ohm |
| Card Reader | Support SD/MMC card up to 8GB |
| USB Port | USB 2.0 host (5v, 800Am) |
| Built-in Speaker | 2 x1W, 8 ohm |
| Power Adaptor | AC 100~240V 50~60 Hz<br>DC 12V/1.0A |
| Power consumption | < 10 W |
| Dimensions | 238x145x24mm |
| Net Weight | 524g |



**Media Formats**

| | | |
|---|---|---|
| Video player | File Type | AVI,MPG,ASF,VOB |
| | Video Type | MPEG1, MPEG2, MPEG4 |
| | Audio Type | MPEG1/2, Layer 1/2/3, PCM, LPCM |
| | Audio bit Ratio | 32Kbps ~ 320Kbps |
| | Resolution | Max. 720 x 480 |
| | Frame Rate | Max. 30fps/25fps(PAL) |
| | Caption | DIVX(4.0, 5.0), XVID |
| Music player | File Type | MP3,WMA |
| | Bit Ratio | 32Kbps~320Kbps |
| Photo viewer | File Type | JPG,JPEG(not include non--interlace) |
| | Resolution | Up to 4000 x 3000 pixels |

## 12. Troubleshooting

Problems listed below do not necessarily signify a fault with the unit.
Please check this list before requesting repairs.

| Problems | Possible Causes and Solutions |
|---|---|
| No picture and no sound | Check the connection with the AC adaptor or car adaptor. Use of an unauthorized power supply. Press POWER on the remote to turn on the device, or press and hold POWER on the device for 1.5 seconds to turn it on. |
| No image | Check the channel selection. Scan for channels again. Always rescan for channels in new locations. |
| No sound | Check the sound volume. If you are using earphones, test them on another item. Check the earphone cable is plugged into the earphone socket on the device. Incorrect TV Format setting in Analogue TV mode. Set the device to factory default, then try again. |
| Picture freezing, and/or sound distorting | Signal too weak, please check the aerial. Try to use a proper roof top aerial or an amplified aerial. |
| No signal | Signal too weak, please check the aerial. Try to use a proper roof top aerial or an amplified aerial. |
| Dark Picture | Please adjust Brightness and/or Contrast settings. |
| Snowstorm | Motors/Trains/High Voltage Lines and Neon Lights may affect the signal. |
| Achromatic/Flashing/No Colour | Please adjust the Colour Setting. Incorrect TV Format setting in Analogue TV mode. |

### ⚠ Warning

This operation instruction is only intended for reference. No further notice is available to any modification of all information contained therein. Due to continuing improvements, the features and design are subject to change without notice.

### ⚠ Warning

No user serviceable components are fitted inside this TV. Do not attempt any repairs, as this will invalidate the warranty. Any repairs must be carried out by either the manufacturer or their nominated service centre. Parts inside this set are subject to high voltage.



## ■ Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased
- The product must be correctly installed and operated in accordance with the instructions given in the user's manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufacture disclaims any liability for incidental or consequential damages.
- Please consult our customer service before returning any product; we are not responsible for any unexpected product returns.
- Any faulty products must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Please note:

1.A LCD display panel comprises a very large number of pixels and each pixel contains three sub-pixels - red, green and blue. Due to the complex manufacturing process, occasional pixel anomalies may occur. Pixel anomalies cannot be fixed or repaired and can happen at any stage in the LCD's life. August products should not be deemed as faulty if there are no more than three bright and dark pixels respectively.

2.Portable TV antennas included in the box are for people to watch Freeview TV in areas where the signal is very strong and there may be difficulties in receiving signal with the included portable antennas in some regions at present. This is due to the fact that Freeview is yet to operate in full power in the UK. August TVs should not be deemed as faulty if it can receive Freeview by connecting to a proper digital rooftop aerial.

**Customer Service:**
Telephone: +44 (0) 845 250 0586
Email: service@augustint.com